

LUXOR H. WILSON

MB3624 - MB4836 - MB7240
MB3040 - MB3648
Mobile Board Assembly Guide

Note: After assembly, remove the protective film from both sides of the board.
Cleaning Tip: A mild dish washing liquid can be used with a soft cloth to clean the writing surface.

