


# REPLACEMENT INSTRUCTIONS

## HEATED DISPLAY CASE FRONT DECAL

**SERVITE** HOLD IT  
HEAT IT  
MOVE IT



### STEP 1

Take out the upper left and right pads.





### STEP 2

Remove the upper cover.



### STEP 3

Remove components on the front panel.



### STEP 4

Replace new front decal.

