
HOW TO CLEAN THE FOB during scheduled Line Cleaning.





Disconnect Keg(s)

and connect to cleaning system.



Push Up Float Release

allowing the cleaning solution to circulate through the FOB in either direction.



Push Down & Hold Vent Knob

while cleaning until the chamber is full and cleaning solution vents out the drain line, cleaning the chamber, vent and drain.



Rinse with Water

Repeat step 3 while rinsing the system with water.



Push Down & Hold Vent Knob

while rinsing until the chamber is full and water vents out the drain line rinsing the chamber, vent and drain.




Pull Down Float Release

CLEAN


RINSE





Learn more about Draft Beer Systems at www.micromatic.com







Disconnect Empty Keg

and tap a fresh keg.

2

Push Down & Hold Vent Knob

to refill chamber completely with beer. While venting, a small amount of beer and foam will escape through the drain line.



Push Up Float Release

to allow the float to rise to top of chamber and allow beer to flow to the faucet.




Pull Down Float Release

resetting the FOB to normal operation.

The **Float Release** must be in the pull down position for proper operation.

PRO-MAX-3

MICRO MATIC



01412-D1013

Learn more about Draft Beer Systems at www.micromatic.com