SC3000 How To									
			Prepare for Use						
1	This is how the machine should look when you enter the room.	2	Disconnect battery charger, store onboard charger cord and lower the recovery tank.	3	Inspect and Install proper pad or brush.				
4	Cylindrical Brush Install Turn on machine. Lift deck then turn machine off. Unscrew knobs and remove skirt assemblies. Remove lids by pressing knobs downward. Install cylindrical brushes, install lids and fasten with knobs. Install skirt assemblies and fasten with knobs.	5	Make sure recovery tank is empty. Inspect ball float cage to ensure it is clean and the ball moves freely.	6	Inspect the debris catch cage (<i>if applicable</i>). Empty if needed.				
7	Remove and inspect rear squeegee and blades.	8	Install squeegee (do not over tighten thumb nuts) then attach hose.	9	Fill machine with water (add detergent as required). Fill with water only if using EcoFlex (refer to owner's manual).				
10	Prepare to transport machine to working area by turning machine on.	11	Image: constrained and constra	12	Use foot pedal to drive forward. Use reverse paddle for backward movement.				





SC3000 How To										
Scrubbing										
1	To begin scrubbing, Press the one touch scrub button.	2 Press the foot pedal to move machine forward to begin scrubbing.	3 To stop scrubbing, press the one touch scrub button.							
		SC3000 How To								
	Ac	djustments while Scrubbing	g							
1	Use the Burst of Power to increase detergent strength and cleaning power.	2 Apply extra scrub pressure as needed for more cleaning power.	3 Adjust solution flow rate if more or less water is needed for the task.							
4	Apply quiet mode to reduce sound level when cleaning near classrooms or offices.	For the second s	Otherwise the suggested ratio 9							
		Scrubbing Tips								
1	 Start and stop scrubbing while in motion Avoid 180 degree or sharp turns 	 Scrub the perimeter first, then the inside Keep the squeegee down and vacuum as long as possible 	 Use the least amount of pressure, water and chemical possible Use the burst of power to clean dirtier areas Transport up ramps, scrub down ramps 							
Nilfisk		Page: 2								



NilfiskU.com

SC3000 How To								
SC3000 HOW TO Store the Machine (Daily Maintenance)								
1	Empty the recovery tank. Drain water into an open drain. Rinse recovery tank, ball float and debris catch cage.	2	Remove, rinse and inspect squeegee blade then hang on the back of the machine. Remove, inspect and wash brushes and pads.	3	Open seat compartment for ventilation, charge batteries, clean exterior of machine.			
	· · · · · · · · · · · · · · · · · · ·	We	ekly Maintenance		·			
1	Inspect battery water level (add distilled water if needed).	2	Clean solution filter.	3	EcoFlex system purge Turn on machine. Press detergent flow switch and solution flow increase switch at the same time until the Washing detergent flow control flashes. Collect detergent then turn ignition to 0. Lift the dumping recovery tank to make sure it's empty. If not repeat steps again.			
		0	ther Maintenance					
Monthly Mtce.	 Lubricate machine Equalize batteries Refer to the operator manual for specific instructions. Some items should only be performed by an Authorized Advance Service Center. 	Annual Mtce.	Brush/pad-holder motor carbon brush check/replacement. Vacuum and drive system motor carbon brush check/replacement. <i>Performed by Authorized</i> <i>Advance Service Center</i>	9	Sc3000 26" Disc sc3000 28" cyl.			

Nilfisk

NilfiskU.com