











SC750/SC800 How To

Prepare for use

<p>1</p>  <p>This is how the machine should look when you enter the room.</p>	<p>2</p>  <p>Unplug battery charger. Wrap cord accordingly.</p>	<p>3</p>  <p>Inspect recovery tank and ball float cage then lower the lid.</p>
<p>4</p>  <p>Fill solution tank with water (do not exceed 130°F). Add appropriate cleaning chemical.</p>	<p>5</p>  <p>Do not mix detergent in the tank for EcoFlex models (fill cartridge).</p>	<p>6</p>  <p>Inspect squeegee blade, install squeegee on machine (<i>attach recovery hose to the squeegee inlet</i>).</p>
<p>7</p>  <p>Inspect and install brush or pad.</p>	<p>8</p>  <p>Install brush or pad-holder under the deck.</p>	<p>9</p>  <p>Install brush for (<i>Cylindrical models</i>).</p>
<p>10</p>  <p>Safely transport machine to desired work location.</p>	<p>11</p>  <p>Turn on machine. Verify there is enough battery life to complete job. Choose appropriate controls for the job.</p>	<p>12</p>  <p>Turn on scrub switch, lower squeegee and begin scrubbing.</p>





SC750/SC800 How To

Store the Machine







<p>1</p>  <p>Empty recovery tank and solution tank. Empty water in suitable drain or bucket.</p>	<p>2</p>  <p>Wash recovery tank and solution tank thoroughly with clean water.</p>	<p>3</p>  <p>Inspect and clean vacuum shut off and debris catch cage.</p>
<p>4</p>  <p>Inspect hoses; replace if kinked or damaged.</p>	<p>5</p>  <p>Remove, rinse and inspect squeegee. Replace if needed.</p>	<p>6</p>  <p>Remove, clean and inspect brush or pad. Rinse with warm water. Hang to dry. Replace if needed.</p>
<p>7</p>  <p>Lift recovery tank lid. Allow tank to air dry.</p>  <p>Hang squeegee on the back of machine.</p>	<p>8</p>  <p>Charge batteries.</p>	<p>9</p>  <p>Wipe down exterior of the machine.</p>

SC750/SC800 How To

Daily Maintenance

1	 <p>Charge Batteries daily at the end of the shift.</p>	2	3
4	 <p>Check, clean and rotate the brushes/pads.</p>	5	6
		 <p>Clean and check the squeegee.</p>	 <p>Clean Hopper on (Cylindrical models).</p>

Weekly Maintenance

1	 <p>Inspect scrub housing skirts.</p>	2	3
4	 <p>Clean solution manifolds on Cylindrical models.</p>	5	6
		 <p>Inspect and clean solution filter.</p>	 <p>Check each battery cell water level (does not apply to gel batteries).</p>
		 <p>Purge EcoFlex System: Disconnect and remove cartridge, turn machine ON. Press and hold the solution switch for 2 seconds.</p>	 <p>Monthly: Equalize batteries by fully charging then recharge two or more times. Annually or after 300 Hours: inspect carbon brushes on vacuum motor Annually or after 500 Hours: inspect carbon brushes on the drive and brush motor</p> <p>Monthly: Apply light oil to lubricate machine (see manual for details). Equalize batteries Yearly: Check carbon brushes</p>