


#475TCWHL32ST | #475TCWHL50ST | #475TCWHL64ST | #475TCWHL95ST

# Step Pedal Attachment

For customers who purchased a step pedal attachment with their trash can.

### PARTS LIST


Trash Can (1)



Lid (1)




Step Pedal\* (1)



Wheels (2)



Axle (1)



Step Pedal  
Rods\* (2)



Rod  
Pins (4)




\*Only available with the purchase of the step pedal kit.

**Required Tools:** Flathead Screwdriver (optional for removal of wheels to add step pedal assembly to existing can)


### STEP 1

Stand trash can and lid upright on a flat surface. Position the step pedal assembly so that each arm is on the left or right side of the trash can if the trash can lid handles are facing you. The step pedal should be upright and facing you.




### STEP 2

Locate the two (2) wheels and axle. Insert the axle into one of the wheels until you hear a click.




### STEP 3

Align the wheel and axle with the pre-drilled hole on the left arm of the step pedal assembly and insert the axle through the assembly until the wheel is flush with the step pedal assembly.




### STEP 4

Once the axle is through both holes, insert the remaining wheel onto the exposed axle end facing out of the right arm of the step pedal assembly. Push until you hear another click.




### STEP 5

Take one of the step pedal rods and carefully insert the top end into the pre-drilled hole on the top of the trash can. Then, align the bottom end with the pre-drilled hole in the left arm of the step pedal assembly.




### STEP 6

Insert one (1) of the provided pins through the holes at the top and bottom of the step pedal rod. After being inserted, carefully bend back one or both of the ends of the pin in order to secure the rod to the trash can.



### STEP 7

Repeat steps 5 and 6 on the right side of the trash can using the remaining step pedal rod and two (2) pins.



### STEP 8

Test the step pedal rod by stepping on the pedal. The lid of the can should lift.

Please contact WebstaurantStore customer solutions at [help@webstaurantstore.com](mailto:help@webstaurantstore.com) if you have any issues with assembly or missing parts.


#475TCWHL32ST | #475TCWHL50ST | #475TCWHL64ST | #475TCWHL95ST

# Step Pedal Attachment

For customers who already own a can that is assembled and purchased a step pedal attachment separately.


### STEP 1

If you are starting with a Lavex rollout trash can that is fully assembled and wish to attach a step pedal assembly, first locate the spring on the inside face of each wheel.



### STEP 2

Using a flathead screwdriver (not included), carefully use the screwdriver to depress the spring on the left wheel. This will cause the wheel to loosen, allowing you to remove it from the axle.



### STEP 3

Repeat this same process on the right wheel to remove the wheel and axle from the trash can bottom.

### STEP 4

Proceed with Steps 1 - 8 of the Step Pedal Assembly process above.

