



THERMAL FRESHTRAC™ (TFT) GUIDE AND CLEANING INSTRUCTIONS



TFT64
64 Ounce Dispenser
With FreshTrac™ Lid

TFT64D
64 Ounce Decaf Dispenser
With FreshTrac™ Lid

TFT64/TFT64D COMPONENTS



FRESHTRAC™ LID

STEM



ACTIVE LED LIGHTS

Green and red LED lights blink to indicate the freshness and volume of the coffee

TFT64/TFT64D LED LIGHT GUIDE

LIGHT COLOR	MEANING
Green/Red/Green	Activation/Reset.
Green	Time: Coffee is fresh. There are 11 or more minutes remaining on the Quality Timer. Volume: Dispenser contains more than 24 ounces of coffee.
Red	Time: The Quality Timer has expired. Volume: The dispenser is empty.
Green/Red	Time: The Quality Timer is almost expired. There are 10 or less minutes remaining. Volume: The dispenser is almost empty. There is approximately 12-24 ounces of coffee remaining.

TFT64/TFT64D GUIDE TO LED DISPLAY ACTIVITY*

Brewing coffee into an empty TFT Server

LED Display Activity:

- The LED lights will flash Green/Red/Green to indicate activation or reset.
- As the server fills with coffee:
 - The LED will flash Green/Red until the volume inside the server exceeds 24 ounces and then change to Green only, flashing every 6 seconds.
- The Quality Timer will reset.



The coffee is fresh and the TFT Server contains more than 24 ounces of coffee

LED Display Activity:

- The Green LED Light will flash every 6 seconds.



*Photos show example display information only.

The Quality Timer has expired

LED Display Activity:

- The Red LED Light will flash every 6 seconds for one hour.



The TFT Server is empty

LED Display Activity:

- The Red LED light will flash every 6 seconds for any time remaining on the Quality Timer and then for an additional hour.



The Quality Timer has expired AND the TFT Server is empty

LED Display Activity:

- The Red LED light will flash every 6 seconds for one hour.



The Quality Timer is ALMOST expired (10 minutes or less remaining)

LED Display Activity:

- The Green and Red LED lights will flash in a Green/Red sequence every 6 seconds.



The TFT Server is ALMOST empty (approximately 12-24 ounces remaining)

LED Display Activity:

- The Green and Red LED lights will flash in a Green/Red sequence every 6 seconds.



The Quality Timer is **ALMOST** expired and the TFT Server is **ALMOST** empty

LED Display Activity:

- The Green and Red LED lights will flash in a Green/Red sequence every 6 seconds.



RESET AND WIPE THE TFT STEM CLEAN BEFORE EACH BREW CYCLE

Keeping the TFT stem free from coffee oil build-up ensures that accurate time and volume information is displayed. Before each brew cycle, wipe TFT stem clean and invert (as shown) for 30 seconds. Replace and brew.



TFT DISPENSER CLEANING

- 1 Completely empty dispenser before cleaning.
- 2 Place dispenser with brew-thru FreshTrac™ lid under the coffee brewer.
- 3 Remove the brew basket and place cleaning products in the center of the brew basket and replace (see product supplier information for number of cleaning tablets needed).
- 4 Press the brew button to brew hot water and the cleaning solution into the dispenser.
- 5 When the cycle is complete, leave the cleaning solution in the dispenser for approximately 15 minutes.
- 6 Use a cleaning brush to remove coffee oil build-up from inside the dispenser. Empty the dispenser.
- 7 Place under the brewer and run another brew cycle with water only to rinse the dispenser.
- 8 Empty the dispenser and run one more brew cycle with water only.
- 9 Rinse and empty. Dry thoroughly.

CLEANING TOOL



JB-1
(or other similar brush)

TFT COFFEE SERVER PRECAUTIONS

- Do not immerse coffee server in water.
- Do not place in dishwasher.
- Do not use harsh powders or cleaners containing chlorine.
- Do not use a wire brush or pot scour to clean inside liner.