

ASSEMBLY INSTRUCTIONS




Item # TNA2195-Teak & Cable Wicker Parlor Chairs

STOP! PLEASE READ FIRST:


Thank you for purchasing this item from Outdoor Interiors. Please verify all the hardware and components are included as you unpack the carton. Place the items on a safe area to avoid loss and damaging contents. Use a soft area to empty box to assemble the item. Do not fully tighten hardware until all screws and bolts are connected first. Then tighten.

CARE & MAINTENANCE:

We recommend the following maintenance plan to provide longterm care:
 Thoroughly clean 2-3 times a year with a soft rag, warm water and mild detergent and wipe dry.
 For tough stains, gently scrub with a soft brush or cloth only, rinsing well and drying.
 Avoid standing water or sprinklers from hitting your furniture regularly as this will cause staining and uneven grain and finish concerns. Always cover your furniture when not in use during extended periods.



Hardware List

A	 M6x45	2pcs
B	 M6x20	4pcs
C	 Allen Key 4	1pc

