Project:	Date:	Approval:	Qty:	Item #: 554BP10X15W



Backyard Pro Courtyard Series 10' \times 15' White Straight Leg Steel Instant Pop Up Canopy Tent

#554BP10X15W







Technical Data

Length	10 Feet
Width	15 Feet
Maximum Height	120 - 132 Inches
Color	White
Features	UV-Resistant
Frame Material	Steel
Material	100% Polyester
Shape	Rectangle
Style	Straight Leg
Туре	Canopies

Features

- Provides up to 150 sq. ft. of shelter for patrons, employees, and equipment
- Rising truss ceiling system offers additional headroom
- Easy-to-use canopy sets up quickly to save time and labor during event preparation; stakes and ropes
- Top is water resistant, flame-retardant, and filters out harmful UV rays
- Steel frame features a powder-coated finish

Notes & Details

This Backyard Pro $10' \times 15'$ white steel straight leg steel instant canopy offers commercial grade durability with recreational grade portability and affordability, making it easy to work your next event in style and comfort! This 100% polyester canopy provides an easy way to draw attention at trade shows or provide shade and shelter during outdoor events. Its powder-coated steel frame and eye-catching white canopy top combine to ensure optimum visibility, near or far.

This Backyard Pro canopy features a rising truss ceiling system that combines the benefits of the full truss system's strength with reinforced truss bars, offering additional headroom similar to a cathedral-style frame. The steel frame is durable and built to withstand heavy use. It's perfect for outdoor events, providing up to $150 \, \text{sq}$. ft. of shade beneath the $10' \times 15'$ canopy. Plus, the 4-legged design ensures stability and safety for staff and guests alike.

Crafted from water-resistant fabric, this canopy offers protection for your guests, equipment, and employees during light to moderate rain, and the top fits snugly over the frame for a seamless look and easy set-up. This canopy is so simple to set up, it only takes a few minutes with the work of two employees to complete saving time and labor during event preparation! Set the frame on its feet. Begin pulling the legs out while still keeping the top of the frame at an easily reachable level. Once the frame is partly expanded, add the cover on top with each corner fitting over a leg. Continue to pull the legs in opposite directions until they're out as far as they will go and lock into place. Finally, raise the height of each leg by lifting the upper portion, stopping when each leg locks into place. Tear down is just as easy. Remove the top, adjust the legs back to their lowest height, disengage each corner's locking button, and gently push together until the frame is once again folded fully. A roller bag is included to ensure that you have an easy way to store and transport the canopy frame.

WARNING: This product can expose you to chemicals including lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.p65warnings.ca.gov.