

*Plates suitable for:
Oven, Dishwasher & Microwave*

CREAMY WHITE



DINNERWARE

CRISM

CRISM

				
CRISM-24 Charger Plate 12" cp: 12	CRISM-1 Dinner Plate 11" cp: 12	CRISM-2 Luncheon Plate 9.25" cp: 24	CRISM-4 Salad/Dessert Plate 7.8" cp: 24	CRISM-5 B&B Plate 6.1" cp: 24
				
CRISM-41 Soup Plate 12" cp: 12	CRISM-3 Round Rim Soup Plate 9.25" cp: 12	CRISM-7 Bowl 6", 27oz cp: 24	CRISM-11 Soup Cup W/ Handle 3.75", 8oz cp: 24	CRISM-12 Soup Cup 8oz cp: 24
				
CRISM-28 Mug 3.4", 11oz cp: 36	CRISM-9C Stackable Cup 6oz cp: 24	CRISM-9S Saucer 5.9" cp: 24	CRISM-22 Oval Rim Platter 14.3" cp: 6	
				
CRISM-428C Espresso Cup 3oz cp: 48				
				
CRISM-428S Espresso Saucer 4.7" cp: 48				