



- Add European style while creating dispense excitement.
- Condition the glass before pouring invert glass, push down on sprayer for cold water rinsing.
- Draft tower mounts directly to platform tray eliminating coring of counter top.
- Robust 18 gauge stainless steel module with full plywood under support.



Feature



<u>www.micromatic.com</u> 1 (866) 327-4159

Job Number: Location:____




Part No.	Description	Shipping Weight	Box Dimensions
DP-1611	Polished Stainless Steel	14 kg	1308mm L x 552mm W x 64mm H
		30 lbs	51 1/2"L x 21 3/4"W x 2 1/2" H

Rinser Water Inlet Installation

- · Always check local plumbing codes first.
- Install in-line water regulator set at 15 PSI from the street water supply (no greater, perfect operating pressure).
- · Install in-line one way check valve from the street water supply (prevents pressure drop which can cause leaking).
- Install in-line shut-off for the rinser system from the street water supply (this must be turned off nightly).
- If teed into soda system make sure system can handle the increased water demand. Have plumber install a 45° 1/2" O.D. barb for the drains if line is not hard plumbed into the system.
- Install a shut-off for the rinser water supply if line is not hard plumbed into the system.

Dimensions





Toll Free: 1-(866) 327-4159				
West	Central	Southeast	Northeast	
19791 Bahama Street	10726 North Second Street	2364 Simon Court	4601 Saucon Creek Road	
Northridge, CA 91324	Machesney Park, IL 61115	Brooksville, FL 34604	Center Valley, PA 18034	
Tel. (818) 701-9765	Tel. (815) 968-7557	Tel. (352) 799-6331	Tel. (610) 625-4464	
Fax. (818) 701-9844	Fax. (815) 968-0363	Fax. (352) 796-2429	Fax. (610) 625-4466	