

# Fine Dine

Fine Dine's ultra-sleek line gives it a timeless elegance. Chefs love the vast array of items which make up this series for desserts, breakfasts, and starters. Wide rims and playful shapes add visual punch.



## FLAT PLATES



- FDFP33 13" D 6
- FDFP31 12½" D 6
- FDFP29 11½" D 12
- FDFP27 10¾" D 12
- FDFP25 9¾" D 12
- FDFP22 8¾" D 12
- FDFP16 6¾" D 24

## GOURMET FLAT PLATES



- FDGF33 13" D 6
- FDGF29 11½" D 12

## DEEP PLATES / PASTA BOWLS



- FDDP31 26 oz 12½" D 6
- FDDP23 12½ oz 9" D 12

## DEEP COUPE PLATE / PASTA BOWL



- FDDC27 52¾ oz 10½" D 6

## GOURMET DEEP PLATES / PASTA BOWLS



- FDGD29 55¾ oz 11½" D 6
- FDGD26 42¼ oz 10¼" D 6

## GOURMET DEEP PLATE / PASTA BOWL COVERS



- FDCL02 6" D 6
  - FDCL01\*\* 5½" D 6
- \*Compatible with FDGD29  
\*\*Compatible with FDGD26

## OBLONG PLATTERS



- FDOP46 18½" L 8¾" W 12
- FDOP40 15 ¾" L 7½" W 12

## OBLONG PLATTER



- FDOP30 11½" L 3¾" W 12

## OVAL PLATTERS



- FDOP36 14½" L 10¾" W 6
- FDOP34 13¾" L 10" W 6
- FDOP26 10¼" L 7¾" W 12
- FDOP22 8¾" L 6¾" W 12
- FDOP17 6¾" L 5" W 12

## OVAL SALAD BOWLS



- FDBO24 37½ oz 9½" L 6½" W 3¾" H 6
- FDBO27 36¾ oz 10½" L 7¾" W 2¼" H 6
- FDBO16 10¾ oz 6¾" L 4¾" W 2" H 6

## ROUND SALAD BOWL



- FDBS23 49% oz 9" D 12

**ROUND BOWLS**



**FDBI8** 36% oz 7" D 6  
**FDBI4** 15% oz 5½" D 12  
**FDBI2** 9% oz 4½" D 12  
**FDBI1** 7% oz 4½" D 12  
**FDBI08** 3% oz 3½" D 12

**EXTRA THICK ROUND BOWL**



**FDBI14M** 15% oz 5½" D 12

**LIDS**



**FDBI14LD** 5½" D 12  
**FDBI11LD** 4¾" D 12  
 COMPATIBLE WITH FDBI14 & FDBI11

**COFFEE POTS W/ LIDS**



**FDCP70** 23¾ oz 4½" D 6½" H 4  
**FDCP35** 11% oz 3¾" D 4¾" H 4  
**Replacement Lid for FDCP70**  
**FDCPLD2** 3½" D 12  
**Replacement Lid for FDCP35**  
**FDCPLD1** 2¾" D 12

**TEAPOTS W/ LID**



**FDTP80** 27 oz 5" L 4  
**FDTP40** 13% oz 3½" L 4  
**Replacement Lid for FDTP80**  
**FDTPLD2** 12  
**Replacement Lid for FDTP40**  
**FDTPLD1** 12

**CREAMERS**



**FDCR40** 13% oz 3½" D 4½" H 6  
**FDCR25** 8% oz 3¾" D 4" H 6  
**FDCR15** 5 oz 2¾" D 3¾" H 6  
**FDCR05** 1% oz 1¾" D 2½" H 24

**SOUP BOWLS W/HANDLES**



**FDCS35** 11% oz 4½" D 6  
**FDCS30** 10% oz 3¾" D 6

**SOUP BOWL W/O HANDLES**



**FDCS01** 11% oz 4¾" D 6

**CUPS**



**FDCU30** 10% oz 3¾" D 12  
**FDCU25** 8% oz 3¾" D 12  
**FDCU20** 6¾ oz 3" D 12  
**FDCU09** 3 oz 2½" D 12

**SUGAR BOWL W/ LID**



**FDSU22** 7% oz 4" D 6  
**Replacement Lid**  
**FDSULD** 12

**SALT SHAKER**



**FDSS01** 1¼" D 2¾" H 6

**PEPPER SHAKER**



**FDPS01** 1¼" D 2¾" H 6

**CUPS W/O HANDLES**



**FDCU30M** 10% oz 3¾" D 12  
**FDCU09M** 3 oz 2½" D 12

**SAUCER**



**FDSA19** 7½" D 12  
 Compatible with FDCS35/FDCS01

**SAUCER**



**FDSA17** 6¾" D 12  
 Compatible with FDCU30/FDCU30M1/FDMU30

**SAUCER**



**FDSA15** 6" D 12  
 Compatible with FDCU25/FDCU20

**SAUCER**



**FDSA13** 5" D 12  
 Compatible with FDCU09

**MUG**



**FDMU30** 10% oz 3¾" D 12

