

Cleaning and Sanitizing

Refer to product manual for complete cleaning/sanitizing instructions.

Zie de handleiding voor het product voor alle reinigings-/sterilisatie-instructies.

Reportez-vous au manuel du produit pour connaître les instructions complètes de nettoyage/désinfection.

Eine komplette Reinigungsanleitung finden Sie im Produkthandbuch.

Pełna instrukcja czyszczenia/dezynfekcji znajduje się w instrukcji użycia produktu.

Consulte el manual del producto para ver las instrucciones completas de limpieza y desinfección.


Fullständiga anvisningar om rengöring/sanering finns i bruksanvisningen.

Fare riferimento al manuale del prodotto per informazioni esaurienti in merito alla pulizia e al risanamento.

Required supplies

- (3) x 7 ounce SafeCLEAN™ environmentally-friendly icemaker cleaner packets
- Nu-Calgon IMS-II sanitizer
- Funnel
- Bucket

Cleaning – Icemaker and dispenser

1. Dispense all the ice out of the unit.
2. Press and hold maintenance/clean switch until  displays in the user interface to enter Maintenance Mode.
3. Remove (unscrew) chrome ice dispense chute.
4. Remove drip tray.
5. Remove (2) screws located behind the drip tray.
6. Move front panel and place on top or beside unit.
7. Remove plug cap from the end of drain tube and lower tube to drain water into bucket.
8. After the system has been drained of water replace plug cap in drain tube.
9. Secure tube in holder.
10. Remove cap from bin lid cover.
11. Screw cap onto ice discharge chute.
12. Mix SafeCLEAN Ice Machine Cleaner, (3) x 7 ounce packets, with three gallons (11.4 L) of water.
13. Pour cleaning solution into bin lid access spout until solution reaches the spout neck.

FOLLETT®
Innovative solutions, inspired by ice

14. Allow the solution to remain in unit for 15 minutes.
15. While machine is cleaning, remove top and right side panel to access and clean air-cooled condenser.
16. Drain system by lowering drain tube into bucket.
17. Secure drain tube into holder.
18. Fill one time with potable water and drain with tube. Secure drain tube.

Sanitizing – Icemaker and dispenser

1. Complete steps 1-11 in prior Cleaning section.
2. Mix a sanitizing solution of 2.5 gallons (9.5 L) of water and 4 ounces (118 ml) of Nu-Calgon IMS-II sanitizer.
3. Pour sanitizing solution into bin lid access spout until solution reaches the spout neck.
4. Allow the solution to remain in unit for 5 minutes.
5. Drain system by lowering drain tube.
6. Secure drain tube into holder.
7. Fill and drain three times with potable water.
8. Place a bucket under the dispense chute and remove cap.

Caution: Some sanitizing solution will remain and drain out when cap is removed. Reposition cap on bin lid spout.

9. Reinstall front panel, ice dispense chute, and drip tray.
10. Press and hold maintenance/clean switch for 5 seconds to exit maintenance mode.

Cleaning – Exterior cabinet

1. Press and release maintenance/clean switch to enter clean mode and disable dispensing.
2. Plastic parts, including the user interface, can be cleaned with non-abrasive cleaners like Windex or Fantastic. Clean stainless steel panels with stainless steel cleaner.
3. Press and release maintenance/clean switch to put unit back into service.

Calgon is a licensed trade name.
SafeCLEAN is a trademark of Follett Corporation.
Follett is a registered trademark of Follett Corporation, registered in the US.

801 Church Lane • Easton, PA 18040, USA Toll free (877) 612-5086 • +1 (610) 252-7301 www.follettice.com	Follett Europe Polska Sp. z o.o. Mokry Dwór 26 c • 83-021 Wiślina, Poland +48 (58) 785-6140 • Fax +48 (58) 785-6159 www.folletteurope.com
---	--

00958264R01