



26301 Curtiss-Wright Parkway Suite 200 • Cleveland, OH 44143

**SUBJECT: ADA Guide: K20H Series Sanitary Napkin and T25 Series Tampon Dispenser
Installation**

The ADA Guidelines to be used for installing Hospeco Brands Group's K20H Series Napkin and T25 Series Tampon Dispensers are as follows:

- Access to vendor should be 39" - 44" above the floor to allow forward and side reach by persons in wheelchairs.
- Unit should be operable with one hand and without tight grasping, pinching or twisting of the wrist.
- Activation of the lever should not require more than 5 lbs. of force when unit is completely filled.
- Do not mount Vendor in a Circulation Path. A Circulation Path is defined by ADAAG as: "An exterior or interior way of passage provided for pedestrian travel, including but not limited to, walks, hallways, courtyards, elevators, platform lifts, ramps, stairways, and landings."

Note: Hospeco Brands Group's K20H Series Napkin and T25 Series Tampon Dispenser mechanisms meet the above ADA guidelines. The mechanism works with a 180° turn. A clenched fist can draw down the Z handle in a straight line, without twisting, with less than 5 lbs. of force.

When installing unit, make sure to mount directly to the wall according to "Mounting Template". Vendor must be secured with all four mounting apertures. The capacity of K20H models is: 15 each #4 Sanitary Napkin Boxes; the capacity for T25 models is: 25 each vended tampons.

Hospeco Brands Group 800•942•9199

Source for Definition: <https://www.access-board.gov/guidelines-and-standards>