


# Fingershield (Push Side)




# INSTALLATION GUIDE

# 1. Draw the first guideline




With the door in the closed position, use a pencil to draw a guideline on the door frame using the 20mm plastic measuring block (provided). Hold it in the vertical position.(20mm).

## 2. Draw the second guideline



Simply repeat the procedure on the door to produce a second guideline.

# 3. Wedge the door open



Now wedge the door in the fully open position.

# Cardea Solutions

Be safe in our knowledge

Distributed throughout the USA by: **LA Baby Company** 


Website:

www.lababyco.com

Email:


 $\underline{customerservice@lababyco.com}$ 

# 4. Remove tape covering




Remove the outer paper layer only off the double sided tape from each side of the Fingershield device.

## 5. Attach Fingershield to door frame



Align the bottom of the Fingershield with the bottom of the door, and then line up the side edge of the Fingershield parallel to vertical guideline on the frame. Press firmly to hold in position before finally securing with the provided screws.

# 6. Now attach it to the door



Repeat this procedure to attach the Fingershield to the door itself.


For metal doors and kickplates it is advised to pre-drill the screw holes with a 2.5mm drill bit.

# Rearshield (Pull Side)



cyclety in Hand


#### 4. Attach Rearshield to door frame



The Rearshield should be set at no more than 15mm above floor level. Ideally level with the bottom of the door. Line up the edge of the Rearshield parallel to the guideline on the frame. Press firmly to hold in position before securing the screws.


# INSTALLATION GUIDE

## 1. Draw the first guideline



With the door in the closed position use a pencil to draw a guideline on the doorframe using the plastic marker (provided) hold it in the


## 5. Now attach it to the door



Repeat this procedure to attach

For metal doors and kickplates it is advised to pre-drill the screw holes with a 2.5mm drill bit.

## 2. Draw the second guideline



Simply repeat the procedure on the door to produce a second guideline.

## 3. Remove tape covering



Remove the double sided tape from each side of the Rearshield

# Fingershield & Rearshield User Guide

### Maintenance

The only maintenance that your Fingershield device requires is an occasional wipe over with a clean damp cloth.

#### Important points to note

Once installed, Fingershield can be removed for door maintenance by unscrewing the exposed screw fixing from the door side, therefore enabling you to gain access to the door and hinges. Once the maintenance work has been carried out, replace the device as in these instructions. In buildings where trolleys, wheelchairs and mobile stretchers are used, staff must be warned to avoid striking the Fingershield device with excessive force, as this may lead to damage. Cardea Solutions UK Ltd cannot be held responsible for this or any other type of damage caused by users.

Manufactured by: Cardea Solutions UK Ltd.
Unit C4, Broadoak Business Pk, Ashburton Road West, Manchester. M17 1RW.
Great Britain