



26301 Curtiss-Wright Parkway Suite 200 • Cleveland, OH 44143

SUBJECT: ADA Guide: Dual EV1, EVNT3, EVNT4, EVNT6 Series Sanitary Napkin/Tampon Vendor Installation

The ADA Guidelines to be used for installing Hospeco Brands Group's EV1, EVNT3, EVNT4, EVNT6 Series Napkin/Tampon Vendors are as follows:

- Access to vendor should be 39" - 44" above the floor to allow forward and side reach by persons in wheelchairs.
- Unit should be operable with one hand and without tight grasping, pinching or twisting of the wrist.
- Activation of the lever should not require more than 5 lbs. of force when unit is completely filled.
- Do not mount Vendor in a Circulation Path. A Circulation Path is defined by ADAAG as: "An exterior or interior way of passage provided for pedestrian travel, including but not limited to, walks, hallways, courtyards, elevators, platform lifts, ramps, stairways, and landings."

Note: Hospeco Brands Group's EV1, EVNT3, EVNT4, EVNT6 Series Napkin/Tampon Vendor mechanisms meet the above ADA guidelines. The coin mechanism on the EV1 series vendor is operated by pushing a button with less than 5 lbs. of force. EVNT3, EVNT4 and EVNT6 series vendors have no-touch operation, place hand in front of sensor to dispense. Mounting of unit should be 74" to top of unit floor, 60" for handicapped accessibility.

When installing unit, make sure to mount directly to the wall according to "Mounting Template" included in each package. Vendor must be secured with all applicable mounting apertures.

Hospeco Brands Group 800•942•9199

Source for Definition: <https://www.access-board.gov/guidelines-and-standards>