CABINET MAINTENANCE

Our cabinets by are designed to be maintenance free. However, it is recommended that the outer surface of the cabinet, and the hinge area, be kept clear from debris and dirt, to ensure correct operation of the hinged door. Manually operate once a year to check functionality of moving parts such as latches, hinges and handles. Periodically clean using a clean dry cloth.

If latches, locks or hinges need to be lubricated, use a "3 in 1" type light oil, removing excess with a cloth.

Glazing: Use a soft cloth and mild soap and water.

Finish	Description	Cleaning
Powder-coat Paint	Baked-on painted Finish	Use a soft cloth and mild soap and water to clean the surface. Rinse
Mill Aluminum	Mill aluminum - no clear coat	
313/315/Clear	Dark bronze, black or clear anodized aluminum	
Plastic/Fiberglass		
US3	Polished & lacquered brass	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US4	Satin finish & lacquered brass	
US9	Polished & lacquered bronze	
US10	Satin finished & lacquered bronze	
US10B	Oxidized & oiled bronze	Use a soft cloth and a paste furniture wax. Buff lightly so as not to remove the dark oxide coating where it remains.
US32, #6, #7, #8	Polished stainless steel	Use a soft cloth and mild soap and water solution. After cleaning, thoroughly rinse with clear water to remove all traces of the solution and wipe dry to prevent water marks from forming. Stains which resist that treatment can usually be removed by polishing in the direction of the grain with a soft cloth and a non-abrasive stainless steel polish. Test in an unobtrusive area.
US32D, #4	Satin stainless steel	



CABINET MAINTENANCE

©2024 ACTIVAR CONSTRUCTION PRODUCTS GROUP, INC.