

## Cleaning Instructions



Cushion Station mats can be cleaned in several different ways.

- They can be commercially laundered (see Laundering Instructions)
- Sterilized in an autoclave
- Washed by hand using the following instructions: Scrub with a deck brush (as needed) using a detergent with a neutral pH. Rinse with a hose or pressure washer. Hang to dry.

## Laundering Instructions



Cushion Station mats can be commercially laundered to remove oil, grease, and soil. The formula below does not require extensive mechanical action or drying; it is designed to dissolve grease residue by using hot water to emulsify oils and grease.

1. Flush 2-3 minutes, high water level, 120 degrees F (49 degrees C)
2. Break 5-10 minutes, high water level, 140 degrees F (60 degrees C)
3. Rinse 2 minutes, high water level, 120 degrees F (49 degrees C)
4. Rinse 2 minutes, high water level, cold
5. Lay mats flat following removal from washer. Allow mats to cool before rolling.