


DECAL APPLICATION & REMOVAL





To Apply Decal

- 1) Lay receptacle on a clean area with the side to be marked facing outward, and decide where you would like to place the decal.
- 2) Separate the translucent transfer sheet from the solid adhesive barrier, along the full length of either side of the decal.
- 3) Tear or cut the separated part of the adhesive barrier off and line up the corners of the decal on the receptacle (Exposed part of transfer sheet will stick to the unit).
- 4) Smooth exposed part of the transfer sheet onto the unit, avoiding creases and bubbles, using the squeegee included to aid in the smoothing of the decal.
- 5) Carefully peel the transfer sheet off of the unit to reveal the symbol/decals.



DECAL APPLICATION & REMOVAL



To Remove Decal

- 1) Lay receptacle on a clean area with decal side facing outward.
- 2) Use the squeegee or your finger to peel up a corner of the decal.
- 3) Slowly and carefully pull the decal away from the surface to avoid ripping and residue.
- 4) Repeat steps 1 and 2 for remaining parts of the decal.
- 5) If there is any residue left on the receptacle, attempt to rub it off with fingers or use warm, soapy water and cloth.

