Technical Information

Oasis - Refrigerated Self-Service Case 26"D

DIMENSIONS / SHIPPING				
Model	L"	L1"	L2"	Est Wt (Ibs)
BN37R	33.125	35.625	0.000	N/A
BN47R	45.125	47.625	0.000	N/A
BN57R	57.125	59.625	0.000	N/A

ELECTRICAL

Model	System Cire	cuit Volts		Ph		Rated Load Amps		Max OCP Amps	Watts	Wires	NEMA Plug	Amps Lights	Amps Fans	Amps Anti- Sweats	Amps Misc/Refrig/ Heat
BN37R	Self-Contained (R290)	Circuit #1	208-240	1	60	10.99	15	15	1,220	2+G	6-15P or L6-15P	0.61	0.44	3.44	6.50
	Self-Contained (R290)	Circuit #1	110-120	1	60	15.14	20	20	485	2+G	5-20P or L5-20P	1.12	0.90	0.12	13.00
BN47R	Self-Contained (R290)	Circuit #1	208-240	1	60	16.00	20	20	1,640	2+G	6-20P or L6-20P	0.61	0.44	3.50	13.00
BN57R	Self-Contained (R290)	Circuit #1	208-240	1	60	16.00	20	20	1,665	2+G	6-20P or L6-20P	0.61	0.44	3.52	13.00

DEE	FRIGE	

					REMOTE REFRIGERATION			GLYCOL / R744 REFRIGERATION					
Model	Zone	Section	System	Envt	SST (°F)	Conv. Rack BTUH	Para. Rack BTUH	Defrost Interval (Hrs)	Defrost Duratio n	Total GPM	Pressure Drop (psi)	Concent (%)	Liquid Temp (°F)
BN37R	All	Refrigerator	Self-Contained-R290	Type II	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
BN47R	All	Refrigerator	Self-Contained-R290	Type II	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
BN57R	All	Refrigerator	Self-Contained-R290	Type II	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

INTENDED	INTENDED ENVIRONMENT					
,,	Type II - Designed to operate in ambient conditions of 80°F and 55% relative humidity unless noted otherwise under Envt above.					
WARMEST	WARMEST AVERAGE PRODUCT TEMP & INTENDED USE OF ZONES					
Zone	Zone Temp (°F) Intended Use					
1 40 Packaged refrigerated products						

IMPORTANT NOTES

1) Performance issues (product temperatures, water on floor, etc.)	
caused by adverse conditions are not covered by warranty.	

- 2) Levelers must be adjusted during installation to ensure unit is level and plumb.
- 3) Keep unit at least 15' from exterior doors, overhead HVAC vents, or any air curtain disruption.
- 4) Do not expose unit to direct sunlight or any heat source (ovens, fryers, etc.).
- 5) End panels must be tightly joined or kept at least 6" away from any structure to prevent condensation.
- 6) Tile floors, low ceilings, or small rooms will increase noise level.
- Compressor air intake at lower front, discharge from lower rear. Lower panels cannot be blocked. Wall spacers required for proper air flow.
- 8) If GFCI is required, a GFCI breaker MUST be used in lieu of a GFCI receptacle.

REGULATORY	
All Models	Accordance with AHRI Std 1200 ETL Listed to UL 471 & UL 60335-2-89 ETL Listed to CAN/CSA 22.2 No. 120 ETL Sanitation to NSF/ANSI 7
WTERTER	In Accordance with


AHRI Std 1200

231-798-8888

888 E. Porter Rd. Muskegon, MI 49441

Technical Information

Oasis - Refrigerated Self-Service Case 26"D



888 E. Porter Rd. Muskegon, MI 49441 231-798-8888

Revised 8/1/2024