


Slatted Steel Can

ASSEMBLY INSTRUCTIONS




LANCASTER[™]
TABLE & SEATING


PARTS LIST:




(A) Receptacle halves
2 Pcs




(B) Receptacle base
and top rim



(C) Flat lid or rain
bonnet lid



(D) Liner
1 Pc



(E) Cable clips
2 Pcs




(F) Security cable
1 Pc

HARDWARE:




(G)
Head Screws
2 Pcs - 4mm



(H)
Hex Head Screws
6 Pcs - 8mm



(I)
Washers




(J)
Allen Key
1 Pc

TOOLS REQUIRED:

- Allen wrench (included)
- Phillips head screwdriver (not included)
- Wrench or heavy-duty pliers (for lid; not included)


STEP 1

On a firm, flat surface, position the two receptacle halves (A) together, lining up the two pre-drilled holes at the top of the receptacle just below the ring. Insert a Phillips head screw (G) into each hole, hand-tightening the screws.



STEP 2

Carefully lift and position the completed basket into the receptacle base (B), lining up the six pre-drilled holes.



Slatted Steel Can


ASSEMBLY INSTRUCTIONS



LANCASTER[™]
TABLE & SEATING


STEP 3

Insert a hex head screw (H) and a washer (J) into each of the six pre-drilled holes located around the base. Do not tighten the screws completely in this step.




STEP 4

Adjust the position of the receptacle halves as needed before tightening all of the hex head screws around the base of the can with the provided Allen wrench. Tighten the Phillips head screws around the top of the trash can with a screwdriver (not included).



STEP 5

Attach the security cable (F) to the cable lock bar on the inside top of the receptacle. Once the cable is attached, loop it through the lid's cable lock bar and use the cable clips (E) to secure the cable tightly.



STEP 6

Insert the rigid plastic liner (C) into the receptacle, setting the lid (D) on the interior hooks at the top of the trash can.

