



Wire Shelving

PARTS LIST


A Shelves




B (4) Posts



C (4) Leveling Feet



D (4) Split Sleeves
per Shelf



E (4) Casters
(if included)



SUGGESTED TOOLS

- Mallet
- Towel



STEP 1

Please ensure that all items are present and none are damaged before assembling.

STEP 2

If assembling a mobile unit, insert the casters into the posts by simply pushing them in. If assembling a stationary unit, push foot leveler inserts into the bottom of the posts.




NOTE: Pushing in the casters/foot leveler inserts may take a bit of force.



STEP 3


Snap (1) split sleeve onto each post for the bottom shelf. Ensure that the split sleeves have the arrow facing up.

NOTE: NSF requires that bottom shelves be at least 6" off the ground.



STEP 4


Hold the bottom shelf on its side and slide each post through the collars in the shelf until the sleeves fit firmly inside the shelf collars.



STEP 5

Stand the unit upright and ensure that the shelf is secured. Use a mallet and towel to firmly seat the shelf onto the split sleeves.

Add additional split sleeves at desired shelf height and continue to place the remaining shelves on top of the posts, sliding them through the shelf slots until the sleeves fit firmly.



STEP 6

If stationary, screw the foot levelers in or out to level the entire unit.

Care and Maintenance

- Please check the weight capacity of each shelf AND the entire unit and stay within the weight recommendations by evenly distributing items on each shelf.
- Dust the shelf or wipe it down with a damp cloth or paper towel to clean off any dirt or debris.
- Placing your shelving unit in the correct environment is essential to getting the longest use out of the unit (place epoxy in moist environments, chrome in dry environments).
- Do not use harsh chemicals on shelving when cleaning to keep the shelves from corroding quicker than normal.
- For Mobile Units: Make sure that casters are in locked position when not moving unit.

Important

The manufacturer is not responsible for damage and/or injury caused by improper assembly, misuse, extended use past the life span, or unbalanced loading of the product. It is the user's responsibility to understand the product's use in each application.