

**LINE:**

**RECEIVING SCALES**

**MODEL:**

**EQB-I 50/100, EQB-I 100/200**

**PICTURE:**



**With a compact  
and economic indicator  
PI Model**

USE	CAPACITIES AND DIMENSIONS		
Storage companies Markets Shipping departments Supermarkets House hold suppliers Steel and aluminum foundries Office suppliers Manufacturers Etc	MODELO	EQB-I 50/100	EQB-I 100/200
	Capacity	50kg/100lb	100kg/200lb
	Minimum division	10g/0.02lb	20g/0.05lb
	Plate Dimensions	48 X 38cm (19"X15")	48 X 38cm (19"X15")

## BENEFITS

- Easy to use
- Heavy duty use
- Toggles between kg and lb
- PC or Printer communication function
- Operates with rechargeable battery (24 hours approximately) or electrical power supply

**LINE:**

## RECEIVING SCALES

**MODEL:**

EQB-I 50/100 & EQB-I 100/200

### BENEFITS



#### BUILT TO LAST

Its solid structure and design, guarantee years of continuous trouble free operation.



#### EASY TO USE

So simple to use that anyone can operate it with only a minute training

### SPECIFICATIONS

	EQB-I 50/100	EQB-I 100/200
Capacity	50kg/100lb	100kg/200lb
Minimum division	0.01kg/0.02lb	0.02kg/0.05lb
Display	Liquid crystal display	
Serial port	Included	
Rechargeable Battery	Included (24 hours approx.)	
Maximum tare	50 kg/100lb	100 kg/200lb
Plate Dimensions	38 x 48 cm (15 x19" IN)	
Backlight	Included	
Cars lighter adapter	Optional	
Power Supply	110v/60hz (220v/50 hz Optional)	
Operation temperature	-10 to 40 °C (14 to 104 °F)	
Storage Temperature	-20 to 50 °C (-4 to 122 °F)	
Net weight	14.5kg/32lb	14.5kg/32lb
Shipping weight	18kg/39lb	18kg/39lb

### OPTIONAL ACCESORIES



Stainless steel plate



Enameled carbon steel table (29 inch) with lead free epoxy finish



Car lighter adapter to plug in the scale

### OPERATES ANYWHERE

The EQB-I operates anywhere with a rechargeable battery (24Hrs, approx.) Power supply adapter



### PC COMMUNICATION FUNCTION

Includes PC or printer interface through RS-232 serial port



### EASY TO READ DISPLAY

Just place the product on the platter and instantaneously read the weight on the display. Saves time and money.



### HEAVY DUTY USE:

It features a central top that prevents damages in the load cell by accidental overloads, which is complemented with the 4 tops at the corners to protect the scale against impacts.

### SECURITY LIDS



The operator does not have access to any function of the PL.




In continuous processes it avoids that the indicator goes OFF accidentally. There is no access to the OFF and ON keys, operator can use only the Backlight, tare, zero and units keys. The programming keys are totally covered.



It avoids the manipulation of the configuration menu and leaves uncovered the keys: OFF, ON, backlight, tare, zero and units.

### DIMENSIONS



DISTRIBUTED BY



ALL INFORMATION IS SUBJECT TO CHANGE WITHOUT NOTICE